







MERCURY I

Fire Retardancy: Australian Standards Only AS1530.3. Results available upon request.

Coordinates with Aruba Sheer & Sheer Blind

CARE INSTRUCTIONS

Do not allow dust to accumulate. Regularly gently vacuum with appropriate attachment. Do not wash. Do not dry clean. Warm iron if needed. Test in inconspicuous area with mild detergent solution prior to spot cleaning. Do not allow blind to become fully wet, use damp cloth only.

Colour matching to previous deliveries or sample swatches cannot be guaranteed.

© Wilson Fabrics Pty Ltd 2005. A Wilson Fabrics Original Design. All Rights Reserved









ROLLER

ROMAN

PANEL